

F16.1

200
i
oper1 Password = "abc^123"

202
)

Service-Type = Login

204 - Cisco: AVPair = "shell:cmd-expr=show .*",

206 - Cisco: AVPair = "shell:cmd-expr=telnet 10\14\0\.[0-9]+",

208 - Cisco: AVPair = "shell:cmd-expr=ping .*"

F16.2





FIG. 3



F16. 4